

HDview

8 CHANNEL TRUE HD DIGITAL
VIDEO RECORDER



FHDV8RX
USER MANUAL



CONTENTS

DVR Description	3
System Connection Diagram	4
Basic Operations	5
Record Setup	10
Main Menu Layout	13
Remote Viewing	14
Help Guide	15

This manual is designed to be used as a quick start guide alongside the informative general user interface (GUI) of the DVR. The menu above is not exhaustive and is designed to lead the user quickly to the most often required aspects of the unit.

The DVR will require a connection to a monitor to be programmed.

IMPORTANT NOTICE

- **Please read this manual** and keep for later use
- Do not use accessory devices not recommended by the manufacturer
- Please use the power adapter equipped for the unit
- Please do not touch any control parts not mentioned in the manual. Incorrect adjustment of a control part not mentioned in the manual may damage the machine
- Ensure air ventilation around the unit and do not cover or block the vent hole
- Do not place the unit in direct sunlight or near a heat source

DVR DESCRIPTION

FRONT PANEL




1. Search - Initiate play back
2. ESC - Exit menu
3. Navigation arrows
4. Menu - Access main menu
5. REC - Access shortcut record menu
6. System indicator lights
7. Remote control receiver
8. USB for mouse or USB stick

REAR PANEL



- | | |
|---------------|---|
| 1. AUDIO IN | Audio input |
| 2. ALARM | Alarm IN / OUT |
| 3. VIDEO IN | 1-8 for video input from camera |
| 4. AUDIO OUT | Audio output |
| 5. VGA | Output for monitor |
| 6. HDMI | Output for monitor |
| 7. LAN | Socket connection for ethernet cable |
| 8. USB 1 + 2 | For mouse control, USB backup and Wifi dongle |
| 9. AUDIO IN | Audio input |
| 10. RS485 + - | Signal Control |
| 11. DC12V | Power input |
| 12. Power | ON/OFF switch |

DVR CONNECTION DIAGRAM



Notes on Camera Connection:

The DVR is specifically designed for High Definition cameras using AHD technology. The DVR can also support standard definition cameras.

BASIC OPERATIONS

CONNECTION TO A MONITOR

Use either HDMI or VGA output to connect to a monitor and select the correct input channel on the monitor.

POWER ON

Plug one lead from the power supply into the 12VDC power supply input marked on the DVR. Turn on the DVR at the mains power point and then select On, on the switch at the rear of the DVR. The Power supply indicator light will illuminate on the DVR's front panel followed by several short bleeps.

POWER OFF

Select Logout from the Shortcut menu and turn off the DVR at the mains power source.

N.B Auto resume after power failure. If the DVR is shut down abnormally, the DVR will automatically backup video and resume previous working status after the power is restored.


MOUSE CONTROLLER CONNECTION

In order to prevent un-authorized tampering majority of DVR functions of are controlled via the mouse controller.

START-UP WIZARD

The **Set-up Wizard** takes the user through basic system settings. More advance options and settings are found in the **Main Menu**.

INTRODUCTION




LOG-IN

An opportunity to change the password is provided within the settings menu. The default settings are:


User Name: admin

Password: 'leave blank'



GENERAL

Set time and date:




The screenshot shows a 'General' settings window with the following fields and options:

- Time Zone: [GMT+08:00]
- System Time: 2016 - 09 - 08 11 : 03 : 41
- Date Format: yyyy mm dd
- Date Separator: .
- Time Format: 24-Hour
- Language: English
- Device No.: 8
- Video Standard: PAL
- Host Name: LocalHost
- Auto Logout: 10 min

Additional options include checkboxes for 'DST' and 'Startup Wizard'. At the bottom, there are four buttons: 'Default', 'Pre Step', 'Next Step', and 'Exit'.

CLOUD

If status is 'Connected' use the QR codes to download the required APP and serial number.



The screenshot shows a 'Cloud' settings window with the following information:

- Enable:
- Status: Connected
- Cloud ID: umksk5xmy3u
- IE Web: www.espkcloud.com

Below the text are three QR codes labeled 'iPhone', 'Android', and 'Cloud ID'. At the bottom, there are two buttons: 'Pre Step' and 'Finished'.

LIVE VIEWING

On start up the DVR will display a divided screen. Using the Mouse Control, double click on any image to bring to full screen. Double click again to return to that main divided screen.

The recording status and alarm status are indicated by the following icons:

Recording



Motion Detect



SHORTCUT MENU

Right-clicking on the live camera screen will activate the Shortcut Menu where the most regularly used settings can be found.

Main Menu	Enter to adjust system settings
Start-up Wizard	Enter to adjust initial system settings
Record Playback	Shortcut for Record Mode
Quick record	To view recorded files
PTZ Control	Settings for Pan Tilt and zoom cameras
Colour Setting	Edit colour settings per channel
Output Adjust	Adjust display output settings of DVR
Logout	Logout, Shutdown or Reboot system
View 1	1 Channel view
View 4	4 Channel view
View 8	8 Channel view (On 8 channel version only)

ACCESSING THE MAIN MENU

Right click the mouse controller anywhere on screen to activate the **Shortcut Menu**.

Selecting **Main Menu** option will automatically display the following screen;

The screenshot displays the HDView software interface. At the top, there is a navigation bar with icons for Record, Alarm, Network, Setting, and Maintain. Below this, a sidebar on the left contains 'Control' and 'Backup' options. The main area shows the 'Record' settings for Channel 1, with a Pre-Record time of 5 seconds and Record Control set to Schedule. A table below lists six schedules, with Schedule 1 being active. At the bottom, there are buttons for Copy, Paste, Default, Save, and Exit.

Week Day	Time Range	Norm.	MD	Alarm
Thu	00 : 00 - 23 : 59	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Schedule 2	00 : 00 - 23 : 59	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Schedule 3	00 : 00 - 23 : 59	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Schedule 4	00 : 00 - 23 : 59	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Schedule 5	00 : 00 - 23 : 59	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Schedule 6	00 : 00 - 23 : 59	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

RECORD SETUP

CONTINUOUS RECORD

As factory set, the unit is programmed to record all channels continuously.

MOTION DETECTION RECORD

Right-click on the screen to bring-up the **Shortcut Menu** select **Main Menu** and log-in

- Select **Record > Control**

Week Day	Thu	Norm.	MD	Alarm
Schedule 1	00:00 - 23:59	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Schedule 2	00:00 - 23:59	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Schedule 3	00:00 - 23:59	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Schedule 4	00:00 - 23:59	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Schedule 5	00:00 - 23:59	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Schedule 6	00:00 - 23:59	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

- Select **Channel** as **ALL**
- Select **Record Control** as **Schedule**
- Select **Week Day** as **ALL**
- Select **Schedule 1** as **MD** only
- Click **Save**
- From the **Main Menu** select **Alarm > Motion Detect**
- Select **Channel** as **ALL**
- Select **Enable**
- Select **Record Channel 1-4/8/16**
- Click **Save** to finish set-up

ADDITIONAL RECORD OPTIONS

Select Main Menu > Record > Record Config.

Channel

Select 1-4/8/16/ All

Pre-Record

The system can automatically archive up to 30 seconds of recording prior to a motion or alarm trigger event

Record Control

Selects the recording preference either by schedule, manual or stop option.

Week Day

Enables recording requirements set for each day

Schedule 1-6

Each day can be segmented into 6 specific recording periods throughout the day

NB. When entering the 'Record > Control' menu the default screen will always start with a display for Channel 1 and the current day's schedule.

RECORDING PLAYBACK

Right click on the live camera view, login and select **Record Playback** directly from the **Shortcut Menu**.



On the playback menu refer to the right hand side of the screen and enter the following;

Standard Playback Operation;

- Main Type: Normal Play
- Select which channel is required
- Select required month
- Select required day
- Click the Play button to begin playback

Event Playback Operation;

- Main Type: Event Play
- Sub Type: Event Type
- Select which channel is required
- Enter Begin and End times
- Select search
- Double click on the event list to start playback


NB. Practice playing back footage to familiarize with the process before an incident occurs.

NB. For best performance it is recommended that only one channel at a time is selected for playback

COPY RECORDING TO USB

Right click on the live camera view and select **Main Menu** directly from the **Shortcut Menu**

- Insert USB stick into DVR
- Select **Record > Backup**



- The details of the USB stick will be visible, Select **Backup**
- Select **Channel** number required
- **Enter Start and End time**
- Select **Search**
- Select **AVI** and Select **Start**
- Notification will be received once complete

NB. Practice backing-up footage to familiarize yourself with the process before an incident occurs.

NB. The AVI file will enable playback via a PC using AVI players

MAIN MENU LAYOUT

Main Menu	Sub Menu	Function
Record	Control	Set the recording configuration, recording type, recording time section
	Backup	Detect or format backup equipment, back the selective files
Alarm	Motion Detection	Set motion detect alarm channel, sensitivity, area and linkage parameters
	Video Mask	Set camera mask alarm channel, sensitivity and linkage parameters if sys. vulnerable to tamper
	Video Lost	Set camera loss alarm channel, sensitivity and linkage parameters if sys. vulnerable to tamper
	Abnormality	Alerts from abnormal operation
Network	Network	Set basic network parameters
	Email	Set email parameters
	FTP	Set FTP parameters
	NTP	Set NTP parameters
	Cloud	View Cloud Connection information
	DDNS	Set DDNS parameters
	UPNP	Set UPNP parameters
	Access Control	IP access control parameters
Setting	General	Time / Date settings
	Encode	Set camera quality control
	Display	Set channel name, icon state, transparency, cover area and time title
	Tour	Set patrol mode and interval time
	PTZ	Set PTZ parameters
	Account	Set User accounts and passwords
	Channel Type	Manufacturer Menu (Do not Adjust)
Maintain	Version	Manufacturer Information
	Configuration	Import Configuration / default system settings
	HDD Manage	HDD Information and options
	Online Users	Displays current remote connections
	BPS	Data consumption rate by channel
	Log	View system Log
	Shut Down	Shut down options

REMOTE VIEWING

Networking should always be carried out by a competent/qualified engineer, specifically when adjusting settings on the router which is sometimes required for remote viewing.

To remote view please refer to the Remote Viewing guide.

Once the DVR has been added to the network there are different methods to view the system remotely:

Smart-phone APP: ESP HDview (IOS/Android)

PC/Laptop Software: HDview CMS supplied on the included CD (Windows compatible)

NB. ESP are unable to guarantee that every device will be compatible with the DVR and software supplied. Specific models of phone, tablet or other device, the hardware it contains, the service provider, the types of data services offered and specific phone / device plan will all affect the performance of PC / mobile device for remote access to the

HELP GUIDE

In the event of trouble with the system please follow the help guide.
If further problems persist please contact the installer / supplier.

The DVR will not boot up normally

- The power supply is not correctly connected/ switched On
- The incorrect power supply is being used
- The power supply is not producing the required voltage
- Disconnect any other devices connected to the power supply / DVR to identify external device trouble

Connection issue with the monitor

- The monitor cable is not correctly connected or is damaged
- The incorrect power is applied to DVR / Monitor
- The correct input channel has not been selected on the monitor
- The correct resolution has not been selected in the DVR's **GUI Display** menu
- Connect a temporary test monitor to adjust the DVR's **GUI Display** menu

There are no cameras displayed on the monitor

- The camera power supply is not correctly connected or damaged
- The camera signal cable is not correctly connected or damaged
- Try another channel input
- There is a connection issue with the monitor

I cannot find the video files in Playback mode

- Recording did not take place in the specified time range
- The recording parameters have not been programmed correctly / switched off
- Hard drive has been overwritten
- Hard drive cannot be detected

Video files not found in Playback mode

- The recording parameters have not been programmed correctly / switched off
- Hard drive has been overwritten
- Hard drive cannot be detected

DVR cannot detect hard disk

- The DVR's power supply is not correctly connected or damaged
- The HDD has not been connected correctly
- An incorrect HDD has been installed

Network connection to DVR is not stable

- Network is not stable
- DVR is not networked correctly
- Incorrect network details have been entered in the remote viewing platform

Elite Security Products

Unit 7, Target Park, Shawbank Rd
Lakeside, Redditch B98 8YN



Telephone: 01527 51 51 50

Fax: 01527 51 51 43

email: info@espuk.com

E&OE - Errors and omissions excepted. I16

www.espuk.com