

UDTAKIT - White | UDTAKITSS - Stainless Steel

Disabled Toilet Alarm

















Manual.indd 1 09/10/2017 13:29:54











RESET MODULE

PULL CORD MODULE









Manual.indd 2 09/10/2017 13:29:55

Overview


1. Pull cord Module 1st pull handle to be 100mm from floor. 2nd pull handle to be mounted 800/1000mm from floor. 2. Reset Module Module to be mounted maximum 1200mm from the floor 3. Input Power, Light and Buzzer Module Activates when the Pull Cord is triggered. Also provides system power input

System designed to comply with care standards BS8300 Installation to be carried out by a qualified electrician.




Manual.indd 3

Kit Wiring Configuration






Maximum Wiring Configuration





Operation Guide







2

Light indication and buzzer will activate



3

Press the RESET button

to reset the system



Manual.indd 6

For backup battery modules please test/replace the battery a minimum of every 12 months & after any duration the system has been powered directly from the battery.

Battery Conditions

Battery level normal (12v-9.6v) Alarm activation for approximately 10 minutes

Battery level low (9.6v-6v) Alarm activation for approximately 4 minutes

Battery level 6v or below Replace battery

Battery Type: A23 Alkaline Battery 12V

Manual.indd 7 09/10/2017 13:29:56







Elite Security Products Unit 7, Target Park, Shawbank Road, Lakeside, Redditch B98 8YN

Tel: +44 (0) 1527 51 51 50

Fax: +44 (0) 1527 51 51 43 www.espuk.com = info@espuk.com





Manual.indd 8