

General

Our products are designed to comply with the recommended codes and practice, and is to be installed and serviced by competent persons in accordance with the relevant regulations.

Contents

The Smart Vibration Sensor is supplied with required batteries, and mount pack.



LED Indicator

LED Indications

Blinks Once-Transmitting

Low Light-Low battery, replace battery

Installation

- Open the case and remove the battery activation strip.
- Mount the sensor firmly on the desired surface.
- Avoid mounting the sensor in areas with a large amount of metal or electrical wiring, such as a furnace or utility room.

Guidance

- > Smart alarm accessories are specified at a maximum of 80 meters Line of Sight (LoS) in open air.
For every obstacle the signal strength is reduced.
- > Battery life depends on working and environmental factors.

For more product information please visit the ESP website
For pairing instructions, please refer to the main Hub Manual.