

ECSPDB


Fort Battery Powered WI-FI Doorbell IP54 with Plug-in Chime

General Information

Our products are designed to comply with the recommended codes and practice, and is to be installed and serviced by competent persons in accordance with the relevant regulations.

Contents


- Smart Doorbell
- 2 x Lithium 18650 Batteries (Ensure battery tabs are removed)
- Mounting Pack
- Micro USB Cable
- Micro SD Card
- RF Chime



Preparation for use

Ensure that the smart phone is connected to the same Wi-Fi network that you would like to attach the device to.


Ensure that you have a mobile device running iOS 8 or higher, or Android 4.1x or higher, and a 2.4 GHz Wi-Fi connection.




Download the ClickSmart+ App on your mobile device from the App Store or Google Play.
Sign in to Register following the instructions on the ClickSmart+ App.

Installation

- Open up the rear cover to insert batteries & Micro SD Card.
- Mount the mount backplate onto the wall, using the 4 holes to mount to the desired surface.
- Push the Doorbell down onto the backplate, and secure with fixing screw.



Ensure the battery tabs have been removed prior to installation.



www.espuk.com

The latest product manuals and software is available online:
https://www.espuk.com/technical_support

Indoor Chime Unit


- The chime unit come pre-paired with the video doorbell. If it doesn't sound when it should, then refer to the below
- Press the 'ring' button, to choose your desired ringtone. The indoor chime offers 36 different ringtones. Each 'press' changes the current ringtone.
- Press the 'Volume' button for 5 seconds, until the music changes.
- Press the doorbell button to match the indoor chime. You can now press the call button on the doorbell, and listen for the chime.
- To change the ringtone, please refer to the above pairing instructions.
- To change the volume, press the 'volume' button once to trigger it. There are 4 different volume levels to choose from, from Low to High.

App Pairing

1. Power up the device VIA the 5V Micro USB Cable, and fully charge the product for at least 12 hours.
2. Once powered up, the LED on the front should be flashing blue, and should say 'The camera is now ready to being pairing'.

The ClickSmart+ app will guide you through:


- Entering the Wi-Fi Network and Password.
- Using the camera to scan a QR Code.
- Connecting the device.



Resetting the Device

If the camera needs to be reset, connected to a new Wi-Fi network, or if it needs to be paired to a new master account, the device will need to be removed from the app prior to resetting the device.

1. Using the system Reset Key, long press the reset button until 'System reset is heard'.
2. The Device should now be reset. After 30 seconds, the unit should start to flash blue, and say 'the system is now ready to begin pairing'.



Guidance

- 8 to 12 hours charge time required for full battery capacity
- Unit requires a minimum of 2 Mbps (upload/download)
- This unit only operates on 2.4GHz
- If the signal strength of your WiFi router is weak; change the router/cameras relative position to receive better signal, use Wi-Fi repeaters/extenders to maximise the range of your Wi-Fi router.
- If the device is installed on a new network, the unit will require resetting.
- If the camera needs to be added to a new account, unbind the device from the first account prior to resetting the device.

For more product information please visit the ESP website.



Elite Security Products UK, Unit 7 Target Park, Shawbank Road, Lakeside, Redditch, Worcestershire, B98 8YN

Tel: +44(0) 1527 51 51 50

Fax: +44(0) 1527 15 01 43

Email: info@espuk.com

Registered in England; Company Registration Number: 02769392; VAT Registration: GB614686525



For more product information please visit www.espuk.com
E&OE - Errors and Omissions Excepted. H24